


1. INDICATION ( INCOMING FIRE ALARM CONDITION )



2. ACKNOWLEDGE ALARM



3. REPEAT THE ABOVE STEPS TO ACKNOWLEDGE ALL ALARMS



4. ISOLATE BELL



5. RESET ALARMS



6. ACKNOWLEDGE RESET

