



## Maintaining Powdercoated Surfaces

### Powdercoated products cannot be regarded as completely maintenance free.

All grades and finishes of powdercoating can stain, discolour or attain a layer of grime if not properly maintained. To achieve the maximum level of corrosion resistance the powdercoated surfaces must be kept clean at all times and free from damage. Provided the grade, condition and surface finish were correctly selected for the particular service environment, fabrication and installation procedures were correct and that cleaning schedules are carried out regularly, good performance and long life will be achieved.

### Maintenance is Necessary

Warm high humidity areas such as indoor swimming pools and bathroom areas can increase the speed of corrosion and therefore need more frequent maintenance. When cleaning powdercoated surfaces it is best to follow the cleaning agents instructions [e.g. warm or concentrated] to avoid further discolouration.

Please follow the suggested methods of cleaning Powdercoated Surfaces listed on page two.



SureCare - a division of Safety Rails Australia Pty Ltd

Suppliers of Grab Rails, Shower Seats, Shower Curtain Track, Sanitary Hardware

a division of Safety Rails Australia Pty Ltd

P.O. BOX 458 Somerton VIC 3062

P +61 3 8339 1200

158 Northbourne Road, Campbellfield, VIC, 3061 Australia

F +61 3 8339 1250

ABN: 12831 726612

[www.surecare.com.au](http://www.surecare.com.au)

E [sales@surecare.com.au](mailto:sales@surecare.com.au)

### Suggested methods of Cleaning Powdercoated Surfaces

- |   |   |   |
|---|---|---|
| ● Routine Cleaning – All Finishes                   | - Soap or Mild Detergent [preferably warm]  | - Sponge, rinse with clean water, wipe dry if necessary.  |
| ● Fingerprints –All finishes                        | - Soap and warm water   | - Rinse with clean water, wipe dry if necessary..   |
| ● Stubborn Stains and Discolouration – All finishes | - Mild Cleaning solutions e.g. - Cream Cleanser   | - Use a rag, sponge [soft fibre or natural bristle – a toothbrush would be perfect]. Rinse well with clean water and wipe dry.  |
| ● Oil or Grease marks – All finishes                | - Organic solvent e.g. – eucalyptus oil, acetone, alcohol, methylated spirits. Baked on grease should be softened beforehand with ammonia | - Clean with soap and water afterwards. Then rinse with warm water and wipe dry.  |
| ● Scratches   | - Use Powdercoat touch up Spray   | - In the event of a scratch penetrating the surface coating, use an approved Dulux touch up spray immediately. Do not leave the scratch untreated for a period of time as corrosion will set in and cause further damage. |
| ● Fingerprints, Stains or Oil or Grease marks       | - Soap or Mild Detergent [preferably warm] or Mild Cleaning solutions e.g. - Cream Cleanser   | - Sponge, rinse with clean water, wipe dry if necessary.  |



**SureCare**



a division of Safety Rails Australia Pty Ltd

SureCare - a division of Safety Rails Australia Pty Ltd

*Suppliers of Grab Rails, Shower Seats, Shower Curtain Track, Sanitary Hardware*

P.O. BOX 458 Somerton VIC 3062

P +61 3 8339 1200

158 Northbourne Road, Campbellfield, VIC, 3061 Australia

F +61 3 8339 1250

ABN: 12831 726612

[www.surecare.com.au](http://www.surecare.com.au)

[sales@surecare.com.au](mailto:sales@surecare.com.au)

### Warranty

20/3/2015

Buxton Construction

PROJECT: Assisi Aged Care

Safety Rails Australia guarantees all materials and manufacture of its products against defects for a period of ten years from date of practical completion.

Safety Rails Australia does not accept liability for any of the following:

1. The failure of the purchaser to meet standard installation requirements
2. The results of inappropriate maintenance
3. Any costs involved in the removal or replacement of faulty products

As per maintenance instructions the grab rails, Monotracks and Sanitary Accessories shall be cleaned [as they will in any hospital] with a soft cloth and non-corrosive type cleaner i.e.: disinfectant.

Our products are of a High Standard and comply with **Australian Standard Code AS 1428.1 2009.**

Everything is supplied as per reverent documents

Kind Regards,  
Stephen McGowan.



SureCare - a division of Safety Rails Australia Pty Ltd

*Suppliers of Grab Rails, Shower Seats, Shower Curtain Track, Sanitary Hardware*

P.O. BOX 458 Somerton VIC 3062

P +61 3 8339 1200

158 Northbourne Road, Campbellfield, VIC, 3061 Australia

F +61 3 8339 1250

ABN: 12831 726612

[www.surecare.com.au](http://www.surecare.com.au)

E [sales@surecare.com.au](mailto:sales@surecare.com.au)